


INSTRUCTIONS for reeving and operating your new **Mini-Mule** Manufactured by DEUER RH-600 ROPE HOIST




Use 3/8" to 1/2" rope, twisted or braided, natural or man made fiber.

Position blocks on a flat surface as shown at left.



TO ASSEMBLE (REEVE) ROPE HOIST:

- (1) Starting at point "A" of upper block, thread rope through lock, around pulley wheel, and out the right side.
- (2) Pull about 7 ft. of rope through the upper block.
- (3) Thread the rope through the front face pulley of the lower block from the right side and out the left side.
- (4) Thread rope through the back face pulley of the upper block from the right side and out the left.
- (5) Thread rope through the back face pulley of the lower block from the right side and out the left.
- (6) Tie or splice rope around the lower bolt of the upper block.



Manufactured & Warranted by

DEUER MANUFACTURING /
INCORPORATED

1100 South Smithville Road, Dayton, Ohio 45403
Telephone (937) / 254-6138 FAX (937) 254-2991
TOLL FREE 866-489-MULE (6853)

Caution

- (1) MAKE SURE ROPE HOIST IS REEVED CORRECTLY BEFORE USING.
- (2) MAKE SURE ROPE HOIST IS NOT FRAYED, WORN, OR DAMAGED BEFORE USING.
- (3) DO NOT LIFT OR PULL MORE THAN 600 LBS (275 KG) RATED LOAD.
- (4) FRICTION BRAKE ENGAGES WHEN EXIT ROPE IS PULLED DOWN AND AWAY FROM LOAD
- (5) FRICTION BRAKE RELEASES WHEN EXIT ROPE IS PULLED DOWN AND TOWARD LOAD.
- (6) DO NOT LIFT PEOPLE OR LOADS OVER PEOPLE.
- (7) MAKE SURE AREA UNDER LOAD IS FREE AND CLEAR OF OTHER OBJECTS AND HAZARDS.

DEUER MFG. THE MINI-MULE PEOPLE MANUFACTURE MANY ACCESSORIES TO HELP YOU DO A JOB WITH THIS ROPE HOIST. FOR FURTHER INFORMATION CONTACT YOUR DEALER, THE FACTORY, OR VISIT WWW.DEUER.COM

THIS IS YOUR **Mini-Mule** ROPE HOIST Manufactured By DEUER

LIMITED SIX (6) MONTH WARRANTY TO ORIGINAL USING BUYER

The upper and lower steel block assemblies of this rope hoist, when operated under normal conditions and within their rated capacity of 600 lbs. (275 Kg.) are warranted against defects in materials or workmanship for six months from date of purchase by the original using buyer.

Any part or unit recognized as defective by DEUER MFG. will be repaired or replaced without charging during this period if it is returned, prepaid to the factory.

This warranty does not cover any claim for labor, delays, or damages.

While this warranty gives you specific rights, you may also have other rights which vary from state to state.

DEUER MANUFACTURING INC | 1100 S SMITHVILLE ROAD | DAYTON | OH 45403 | USA